

Congo Bios Settings Neu

Uhrzeit und Datum einstellen

- **Configuration**
 - **Diskette Options**
 - **Floppy Disk Controller** [Disabled]
 - **Legacy Diskette** [Disabled]

- **Configuration**
 - **Video Configuration**
 - **Primary Video** [PCI]
 - **PCI VGA Adapter Priority** [Last]
 - **Graphics Devices** [128MB]
 - **Internal Graphics Devices** [One]
 - **Memory Size** [UMA=32MB]
 - **Boot Display (s)** [Auto]
 - **Local Flat Panel** [Disabled]

- **Configuration**
 - **Power Control Configuration**
 - **Power Savings** [Disabled]
 - **After Power Failure** [Stay OFF] if has momentary power switch
[Stay ON] if has rocker power switch

- **Configuration**
 - **System Monitors Configuration**
 - **Automatic Fan Control** [Use Setup Options]
 - **Processor Zone Control**
 - **Fan Start** [30°C]
 - **Fan Start Speed** ~~[10%]~~ [20%]
 - **Fan Override tem** [80°C]

- **Boot**
 - **Boot order**
 - **1 : IDE2 : DVD Drive**
 - **2 : IDE0 : Hard Drive**
 - **Floppy Check** [Disabled]
 - **Summary screen** [Disabled]
 - **Boot-time Diagnostic Screen** [Enabled]
 - **Logo Video Mode** [640 x 480]
 - **Quick boot Mode** [Enabled]
 - **Installed OS** [Win XP or later]
 - **Enable ACPI** [YES]
 - **Post Errors** [Enabled]