

ETC® Console Shortcut Keys

Eos Family v2.3.0



To enable Eos functions on Mac Function keys:

- Step 1: Open Systems Preferences
- Step 2: Go into the Keyboard section
- Step 3: Enable the “Use all F1, F2,etc... keys as standard function keys” setting



Note: *Some international keyboards require “Use Shift Key as Eos Shift” to be disabled in the General section of the ECU Settings. Use **Z** as shift to access shortcut functions in these cases.*

Console Key	PC
Shortcut List	;
	?
0	0
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
. (decimal)	. (decimal)
- (minus)	- (minus)
+ (plus)	=
	+
+%	Shift =
	Control Alt =
+% (Mac)	Shift Fn Up Arrow
-%	Shift -
	Control Alt -
-% (Mac)	Shift Fn Down Arrow
/	/
About	Y
Address/Dimmer	Alt A
All NPs	Control N
Assert	Control W
Assert (Playback)	Control Alt A
At	A
	@
	*
Beam Filter	Control B
Beam Palette	Alt B
Blind	F2
	Control 2
Block	B

Console Key	PC
Capture	Control Alt P
Clear	Backspace
Clear Command Line	Shift Backspace
Color Filter	Control C
Color Palette	Alt C
Copy To	C
Cue	Q
Cue Only/Track	X
Data	Control D
Data Mode	Control Shift D
Delay	D
Delete	Delete
Delete (Mac)	Fn Delete
Displays	F9
	Control 9
Effect	Alt E
Effects Softkeys	Alt Shift E
Encoder Display (Gio)	Control Alt \
Encoder Page Color^	Control Alt [
Encoder Page Focus^	Control Alt ,
Encoder Page Form^	Control Alt]
Encoder Page Image^	Control Alt ;
Encoder Page Intensity^	Alt .
Encoder Page Shutter^	Alt ,
Enter	Enter
Escape	Escape
Expand	F5
	Control 5
Fader Pages	Control P
Fader Independent	Shift I
Fan	W
FlexiChannel	F3
	Control 3
Focus Filter	Control F



Corporate Headquarters ■ 3031 Pleasant View Road, P.O. Box 620979, Middleton, Wisconsin 53562-0979 USA ■ Tel +608 831 4116 ■ Fax +608 836 1736
 London, UK ■ Unit 26-28, Victoria Industrial Estate, Victoria Road, London W3 6UU, UK ■ Tel +44 (0)20 8896 1000 ■ Fax +44 (0)20 8896 2000
 Rome, IT ■ Via Pieve Torina, 48, 00156 Rome, Italy ■ Tel +39 (06) 32 111 683 ■ Fax +44 (0) 20 8752 8486
 Holzkirchen, DE ■ Ohmstrasse 3, 83607 Holzkirchen, Germany ■ Tel +49 (80 24) 47 00-0 ■ Fax +49 (80 24) 47 00-3 00
 Hong Kong ■ Rm 1801, 18/F, Tower 1 Phase 1, Enterprise Square, 9 Sheung Yuet Road, Kowloon Bay, Kowloon, Hong Kong ■ Tel +852 2799 1220 ■ Fax +852 2799 9325
 Service: (Americas) service@etconnect.com ■ (UK) service@etceurope.com ■ (DE) techserv-hoki@etconnect.com ■ (Asia) service@etcasia.com
 Web: www.etconnect.com ■ Copyright © 2015 ETC. All Rights Reserved. ■ Product information and specifications subject to change.
 ■ ETC intends this document to be provided in its entirety.

ETC Console Shortcut Keys

Eos Family v2.3.0

Focus Palette	Alt F
Follow/Hang	Shift D
	Control Alt D
Format	F4
	Control 4
(Scroller) Frame	Control Alt C
Freeze	Control Alt F
Full	F
Go	Spacebar
Go To Cue	Control G
Go to Cue Zero	Control Alt G
Group	G
Help	Alt /
Highlight	\
	Control Alt H
Home	Home
	Control H
Home (Mac)	Fn Left Arrow
Intensity Block	Shift B
	Control Alt B
Intensity Filter	Control I
Intensity Palette	Alt I
Label / Note	L
Last	Page Up
	Control ,
Last (Mac)	Fn Up Arrow
Learn	Alt L
Level	V
Live	F1
	Control 1
Load	Control Alt L
Macro	M
Macro 801*	Control Alt 1
Macro 802*	Control Alt 2
Macro 803*	Control Alt 3
Macro 804*	Control Alt 4
Macro 805*	Control Alt 5
Macro 806*	Control Alt 6
Macro 807*	Control Alt 7
Macro 808*	Control Alt 8
Macro 809*	Control Alt 9
Macro 810*	Control Alt 10
Magic Sheet	Alt M
Manual Override	Control Alt M
	Control Alt N
Mirror, Start	Alt F1
Mirror, Stop	Alt F2
ML Controls	F7
	Control 7
More Softkeys	Alt 7

Next	Page Down
	Control .
Next (Mac)	Fn Down Arrow
Off	Control Alt O
Offset	Control O
Out	O
Page Left	Left Arrow
Page Right	Right Arrow
Page Up	Up Arrow
Page Down	Down Arrow
Park	Alt K
Part	P
Patch	::
Path	Control Alt W
Pixelmap	Alt X
Preset	Alt P
Query	Control Q
Rate	Control Alt R
Recall From	E
Record	R
RecordOnly	Control R
Release	Control Alt S
Rem Dim	H
Scroll Lock	F6
	Control 6
Select	Control Enter
Select Active	Control A
Select Last	Control L
Select Manual	Control M
Setup	Alt S
Shift	Z
Snapshot	Control S
Sneak	N
Softkey 1	Alt 1
Softkey 2	Alt 2
Softkey 3	Alt 3
Softkey 4	Alt 4
Softkey 5	Alt 5
Softkey 6	Alt 6
Spacebar Disable	Alt G
Stop/Back	Control Spacebar
Stop Effect	Control Alt E
	Control Alt K
Submaster	S
Tab	Tab
Time	I
Time (Displays)	Shift I
	Control Alt I
Timing Disable	Control Alt T

ETC Console Shortcut Keys

Eos Family v2.3.0

Toggle Hotkeys	F8
	Control 8
Trace	J
Thru	T
Undo	Control X
Update	U
Virtual Keyboard	Control K

*Some Shortcut Key combinations are not available on all physical keyboard layouts.

^Alternatively use Encoder Display + category to change the encoder pages

Shell Shortcut Keys	
Shell Key	PC
0	0
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
. (decimal)	. (decimal)
- (minus)	- (minus)
+ (plus)	=
/	/
Arrow, Down	Arrow, Down
Arrow, Left	Arrow, Left
Arrow, Right	Arrow, Right
Arrow, Up	Arrow, Up
Back	Esc
Clear	Backspace
Delete	Delete
Enter	Enter
Escape	Esc
Select	Return