

J. J. Keller® ELD — USB Micro Tether Installation Guide for Android™ Devices

This tether connects your Android™ mobile device to the J. J. Keller® ELD for wired communication in place of a wireless Bluetooth connection. The tether is designed for mobile devices that use a USB Micro Type-B plug. It is *not* compatible with devices that use a USB Type-C plug, although adapters are available for purchase through retailers. Because the tether will not charge your mobile device, we recommend only using the tethered connection when your device has an additional USB charging port available or will be connected to a wireless charging dock.

1. Connect the end of the USB Micro Tether labeled “ELD” (B) to the USB Micro Type-B port on the front of your J. J. Keller® ELD (A).

NOTE: J. J. Keller’s Gen 2.0 ELD has a large USB Type-A port and a small USB Micro Type-B port. The tether will only fit in the USB Micro Type-B port. The Gen 2.5 ELD only has a USB Micro Type-B port.

2. Connect the other end of the USB Micro Tether (C) to the USB Micro Type-B port on your Android™ mobile device (D). This is the same port used for charging your mobile device (the tether will *not* charge your mobile device).
3. Launch and log in to the J. J. Keller Mobile® application on your mobile device. The software will recognize that you are now using the tethered connection.

